

TYPE 'AL' BUILDING DETAIL AT ROOF

DETAIL AT BASE SAME AS TYPE 'S'.

HN34C ¾" JAM NUT. BUILDING SKID. CUT CORNER BASE AND FLASHING TO MISS HEX COUPLER. TYPE 'S' AND 'AL' BUILDINGS

HR34 - 34" HOIST RING

(5,000 #). SEE NOTE #2.

SEE ROOF PLAN DRAWING

ROOF PANEL

HN34C 34" HEAVY HEX NUT

FOR LOCATIONS.

MATERIAL LIST

SIDE

DESCRIPTION		
3/4" HOIST RING (5,000#)		
20K-LIFT TOP PLATE WITH WELDED NUT		
3/4" THREADED ROD		
3/4" HEAVY HEX NUT		
3/4" GRADE 2H HEAVY HEX COUPLER		

BASE DETAIL

WELD HN34C 34" HEAVY

HEX NUT TO SKID FIRST.

BASE TO MISS.

CUT FLASHING AND CORNER

NOTE:

- 1. CUTTING OF THREADED ROD REQUIRED TO ACHIEVE CORRECT LENGTH. HIGH SIDE IS SLOPED X":12 (ON SINGLE SLOPE BUILDINGS ONLY).
- 2. SITE WORK AFTER BUILDING IS SET AND ANCHORED REMOVE HOIST RING WITH A %" ALLEN HEAD WRENCH (NOT PROVIDED BY PARKLINE). REPLACE WITH K895H605SS 34" BOLT, FW34P 34" FLAT WASHER AND K34RW 34" RUBBER WASHER (FOR TYPE 'S' BUILDINGS). FOR TYPE 'AL' BUILDINGS, REMOVE TOP BEVELED WASHER AND APPLY CAULK TO AREA THAT BEVELED WASHER SETS. RE-INSTALL BEVELED WASHER, K34X1.5SS ¾" BOLT, FW34P ¾" FLAT WASHER AND K34RW 34" RUBBER WASHER.
- 3. EACH SIDE WALL WALL CAP SPLICE MUST BE REINFORCED WITH #774A CAP SPLICE. THIS APPLIES TO ALL 'S' TYPE SIDE WALL CAPS. (NOT USED ON TYPE 'AL' BUILDING)
- 4. ROOF LIFTING SYSTEM FOR BUILDINGS WEIGHING UP TO 20,000 IBS MAXIMUM.

Thomas I Thron

3-2-16

_		
	REVISIONS	BY
ı	03-21-05	RAP
ı	04-22-05	RAP
ı	01-25-06	CEM
I	02-12-07	BHKJ
I	05-15-08	BAS
Į	09-26-08	BAS
I	08-07-09	CEM
I	09-01-09	CEM
I	05-08-14	BMM
ſ	09-28-15	DJM




SCRIPTING SYSTEM 20K LIFTING SYSTEM FOR TYPE 'S' AND 'AL' BUILDINGS

INSTALLATION DETAILS

DATE 6-2-03 DRAWN BY DLR SCALE NTS

ORDER NO. REVISION

20K-LIFT



WELD VOGT POWER INTERNATIONAL V17494-BEXD-5075-02 06-Aug-2016

CN34 ¾" GRADE 2H-HN34C 3/4" HEAVY HEX COUPLER HEAVY HEX NUT 34BKTR-B7 3/4" DIAMETER THREADED ROD. CUT FROM 12'-0" STOCK LENGTHS). TYPE 'S' BUILDING **DETAIL AT ROOF**

MEC/KMEC

REPLACE HOIST RING W/ K895H605SS 34"x1" H.S. BOLT WITH FW34P 34" FLAT WASHER AND K34RW 34"

RUBBER WASHER.

WALL CAP

PLATE20KAX

MATERIAL LIST (PARTS TO SHIP W/ BUILDING)

PART NO.	DESCRIPTION
K895H605SS	3/4" x 1" BOLT (STAINLESS) TYPE 'S'
K34X1.5SS	3/4" x 1 1/2" BOLT (STAINLESS) TYPE 'AL'
K34RW	3/4" RUBBER WASHER
FW34P	3/4" FLAT WASHER